

DIE OPTIMALE POSITIONIERUNG

LX-500/-501 und LX-600/-601



α	0°		1°		2°		3°		4°		5°		6°		7°		8°		9°		10°		11°		12°	
H	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y
Alle Entfernungsangaben in Metern																										
3,0 m	4	> 100	4	> 100	4	> 100	4	> 100	3	> 100	3	> 100	3	> 100	3	> 100	3	41	3	25	2	18	2	14	2	11
3,5 m	7	> 100	6	> 100	6	> 100	5	> 100	5	> 100	5	> 100	4	> 100	4	> 100	4	60	4	36	4	26	3	20	3	16
4,0 m	9	> 100	8	> 100	8	> 100	7	> 100	7	> 100	6	> 100	5	> 100	6	> 100	5	79	5	48	5	34	5	26	4	22
4,5 m	11	> 100	10	> 100	9	> 100	9	> 100	8	> 100	8	> 100	7	> 100	7	> 100	7	99	6	59	5	42	5	33	5	27
5,0 m	13	> 100	12	> 100	11	> 100	10	> 100	10	> 100	9	> 100	9	> 100	8	> 100	8	> 100	7	71	7	50	7	39	6	32
5,5 m	15	> 100	14	> 100	13	> 100	12	> 100	11	> 100	11	> 100	10	> 100	10	> 100	9	> 100	9	82	8	59	8	45	8	37
6,0 m	17	> 100	16	> 100	15	> 100	14	> 100	13	> 100	12	> 100	12	> 100	11	> 100	10	> 100	10	93	9	67	9	52	9	42
6,5 m	19	> 100	18	> 100	17	> 100	15	> 100	15	> 100	14	> 100	13	> 100	12	> 100	12	> 100	11	> 100	11	75	10	58	10	48
7,0 m	21	> 100	20	> 100	18	> 100	17	> 100	16	> 100	15	> 100	14	> 100	14	> 100	13	> 100	12	> 100	12	83	11	65	11	53