


WS-1 not included

All data and dimensions are subject to change


**Free Stand 180**  
**8239-A0000 / 8239-B0000**



WS-1 not included

All data and dimensions are subject to change


**Free Stand 180**  
**8239-A0000 / 8239-B0000**



WS-1 not included

All data and dimensions are subject to change

**Free Stand 180**  
**8239-A0000 / 8239-B0000**




WS-1 not included


All data and dimensions are subject to change

**Free Stand 180**  
**8239-A0000 / 8239-B0000**


When using Free Stand 180 with DLI-230:  
Check if further attachment points are necessary  
to prevent Free Stand 180 from tipping over!



DLI-230



DLI-230  
(fixed installation)  
+ LS-2




DLI-230  
(fixed installation)  
+ LS-4

WS-1 not included

All data and dimensions are subject to change




**Free Stand 180**  
**8239-A0000 / 8239-B0000**



WS-1 not included

All data and dimensions are subject to change

**Free Stand 180**  
**8239-A0000 / 8239-B0000**



WS-1 not included

All data and dimensions are subject to change

**Free Stand 180**  
**8239-A0000 / 8239-B0000**